

USP Bore Paste Instructions...

4 Quick Steps to Optimal Accuracy

Always wrap a cotton patch around a 1-caliber smaller brass core bronze brush for rifle or handgun and a same size brush for shotgun. Use a bore guide if possible to keep the rod centered and protect lands and grooves (and crown). Keep a snug fit by only pushing the patch partially out of the muzzle with each stroke. (Clean from the chamber end if possible).

- 1. Saturate a cotton patch with USP Gun Cleaning Oil and push through the bore. Throw away the patch.
- 2. Put a clean patch on the brush then push through the bore and partially out the muzzle. Apply USP Bore Paste then pull the patch back through the bore and push partially out the muzzle 10-12 times. Throw away the patch. Repeat if necessary. For stubborn fouling, clean when the barrel is warm (from shooting).
- For immediate use, spray the cotton patch with cleaner/degreaser then run through the bore to ensure it's clean and dry. Throw away the patch. Repeat as necessary.
- 4. For storage, simply run a dry patch through the bore and partially out the muzzle. Apply USP Gun Cleaning Oil; then pull back through the bore and push completely out of the muzzle leaving a thick coat of protective oil.